Power Reset Instructions

To reset all devices within the system, switch off the main power switch.
Wait a few seconds and then turn the switch on.

Main Power

Main Power

Main Power